

INSTALLATION INSTRUCTIONS

MODEL IP810 WALK-DRAW GYM DIVIDER CURTAIN

These instructions are intended to be a guide only. They do not imply any responsibility of IPI by Bison for improper installation or faulty workmanship at the jobsite.

1. Identify all parts with packing slip and installation prints.
2. Remove the curtain vinyl from the packing carton and spread out on a clean or protected floor. This will allow for any wrinkles in the fabric to relax.
3. Insert the IPC208 0.175" S-hooks through the grommets located across the top of the curtain. Attach the S-hooks to the jack chain installed on the IPDA8130A trolley assemblies. Close both ends of the S-hooks to secure the curtain to the trolley assemblies.
4. Insert the trolley assemblies into the walk-draw track section while on the ground. Install one IPDC8140 end stop assembly at the end of the track to be installed on the end of the track run.
5. Install the mounting assemblies, furnished for this particular building design, at locations shown on the installation prints.
6. Attach the IPDC8100 hanger clamps to the walk-draw track, spaced as shown on the installation prints, see Figure 1.
7. Raise the first walk-draw track section into place, See Figure 2. This walk-draw track section will contain all of the trolley assemblies and curtain vinyl.
8. Attach the hanger clamps to the mounting assemblies using the IPPC207 0.225" S-hooks. Repeat steps 7 and 8 until all walk-draw track sections have been installed, making sure to install the second IPDC8140 end stop assembly on the other end of the walk-draw run.
9. Install the IPDC8101 splice clamp assemblies to join each walk-draw track section together, see Figure 3. Attach the splice clamps to the mounting assemblies using the IPPC207 0.225" S-hooks.
10. Level all track sections and close all S-hooks to secure all attachment locations.
11. Extend curtain to the full open position, making sure the trolleys roll smoothly through the walk-draw track. Adjust splice clamps, if necessary, at walk-draw track section joints.
12. Install attachment bracket (furnished by others) to wall for use with curtain tie-back strap.



800-637-7968

